

# OPERATING INSTRUCTIONS

## For Prefix CLICK Window Restrictor

### A. OPEN/RELEASE



1. Open window frame fully



2. PULL the locking knob (front of device)



3. PUSH the metallic part, **AND**



4. Same time PUSH apart the inner and outer window frames

---

### B. FIXING TOGETHER



1. SET the head of T screw to hole of metal part



2. PRESS the inner and outer window frames together



3. PUSH the locking knob (front of device)



4. Window is now ready to close